



4.2. Check for Bearing Pressure (Maximum of all the Load Combinations)




The maximum value of Base Pressure is 39.612 kN/m^2 .

4.3. Check for Reinforcement

- **Asx – Top**



- **Asx – Bottom**



- **Asy – Top**

